

6T51 Parts List

BARREL COMPLETE	001-590
CENTER WHEEL	012-770
THIRD WHEEL AND PINION	017-520
FOURTH WHEEL AND PINION	023-700
SWEEP SECOND PINION	025-410
ESCAPE WHEEL AND PINION	032-840
JEWELLED PALLET FORK AND STAFF	035-420
BALANCE WITH HAIRSPRING REGULATED	039-690
RATCHET WHEEL	059-440
WINDING PINION	063-200
CLUTCH WHEEL	064-210
SETTING STEM	065-117
SETTING LEVER	067-142
YOKE	071-220
MINUTE WHEEL AND PINION	072-340
HOUR WHEEL	075-760
SETTING WHEEL	076-270
SETTING LEVER SPRING	077-390
MINUTE WHEEL GUARD	079-250
CASING CLAMP(x2) (OPTION)	082-070
REDUCTION WHEEL	088-150

CAP JEWEL MOUNTED(x2)	094-240
SPIRAL SPRING WITH JEWEL(x2)	098-040
INTERMEDIATE DATE WHEEL	100-200
DATE DIAL DRIVING WHEEL	103-830
DATE DIAL	108-9400
DATE JUMPER	109-420
CALENDAR CORRECTOR LEVER	116-130
DATE CORRECTOR GUARD	117-130
OSCILLATING WEIGHT	119-206
DRIVING GEAR FOR RATCHET WHEEL	138-120
PAWL WINDING WHEEL	141-210
DAY DIAL GIB	178-090
DATE CORRECTOR LEVER	271-090
DAY OF THE WEEK DIAL	308-53XX
MOVEMENT HOLDER (PLASTIC)	500-6621
DIAL SUPPORT RING (OPTION)	502-1444
BARREL BRIDGE	701-486
AUTOMATIC TRAIN BRIDGE	706-065
PALLET COCK	708-054
BALANCE COCK COMPLETE	710-174
CENTER WHEEL COCK	711-052
DATE DIAL GUARD	713-083
YOKE SPRING	902-260

AUTOMATIC TRAIN BRIDGE	708-054
PALLET COCK	708-054
BALANCE COCK COMPLETE	710-174
CENTER WHEEL COCK	711-052
DATE DIAL GUARD	713-083
YOKE SPRING	902-260
FRICTION SPRING FOR SWEEP SEC PINION	903-360
CLICK SPRING	903-950
SCREW FOR AUTOMATIC TRAIN BRIDGE(x2)	921-250
SCREW FOR PALLET BRIDGE	922-180
SCREW FOR BARREL AND TRAIN WHEEL BRIDGE (x3)	922-600
SCREW FOR BALANCE BRIDGE	922-600
SCREW FOR CENTER WHEEL COCK (x2)	922-600
SCREW FOR DATE DIAL GUARD (x2)	922-620
SCREW FOR CALENDAR CORRECTOR LEVER	922-620
SCREW FOR CASING CLAMP(x2) (OPTION)	923-140
SCREW FOR STUD	927-020
SCREW FOR DIAL (x2)	928-150
SCREW FOR SETTING LEVER SPRING(x2)	929-080
SCREW FOR MINUTE WHEEL GUARD	929-080
SCREW FOR DATE CORRECTOR GUARD	929-080
SCREW FOR FRICTION SPRING	933-050
LONGER SETTING STEM (22.55mm)	065-489