

| Item code | Item category | Name |
|-----------|----------------|--------------------------------|
| 012-2170 | Movement Parts | CENTER WHEEL |
| 017-1320 | Movement Parts | THIRD WHEEL & PINION |
| 023-2450 | Movement Parts | FOURTH WHEEL & PINION |
| 025-1010 | Movement Parts | SECOND WHEEL |
| 027-1150 | Movement Parts | LOWER PLATE WASHER |
| 069-1700 | Movement Parts | UNLOCKING LEVER(SWITCH STEM) |
| 072-1050 | Movement Parts | MINUTE WHEEL & PINION 1 |
| 075-4180 | Movement Parts | HOUR WHEEL |
| 078-4300 | Movement Parts | DIAL WASHER |
| 084-5300 | Movement Parts | INTERMEDIATE FOR CHR WHEEL |
| 084-5500 | Movement Parts | FIFTH WHEEL & PINION |
| 087-1020 | Movement Parts | INTERMEDIATE FOR SECOND WHEEL |
| 087-1050 | Movement Parts | MINUTE WHEEL & PINION 2 |
| 087-1630 | Movement Parts | INTERMEDIATE FOR 24 HR WHEEL 1 |
| 087-1640 | Movement Parts | INTERMEDIATE FOR 24 HR WHEEL 2 |
| 100-5400 | Movement Parts | INTERMEDIATE DATE WHEEL |
| 100-5600 | Movement Parts | 24 HOUR WHEEL |
| 103-1120 | Movement Parts | DATE DIAL DRIVING WHEEL |
| 109-5600 | Movement Parts | MODE JUMPER |

| | | | |
|----------|--|-------------------------|-----------------------------------|
| 165-3600 | | Movement Parts | MODE ROCKING BAR |
| 186-6700 | | Movement Parts | SHIELD PLATE |
| 190-1030 | | Movement Parts | STATOR 1 |
| 190-1030 | | Movement Parts | STATOR 2 |
| 190-1030 | | Movement Parts | STATOR 3 |
| 226-3990 | | Movement Parts | SOLAR CELL SUPPORTER |
| 226-4290 | | Movement Parts | CIRCUIT BLOCK SUPPORTING STAND |
| 227-5100 | | Movement Parts | SWITCH STEM SPRING |
| 246-1360 | | Movement Parts | COIL UNIT 2 |
| 246-1670 | | Movement Parts | COIL UNIT 1 |
| 246-1670 | | Movement Parts | COIL UNIT 3 |
| 251-1500 | | Movement Parts | CHRONOGRAPH WHEEL |
| 255-4200 | | Movement Parts | MODE WHEEL |
| 258-3400 | | Movement Parts | MODE SWITCH SPRING |
| 279-B190 | | Movement Parts | CIRCUIT BLOCK |
| 285-1130 | | Movement Parts | |
| 285-1190 | | Movement Parts | ROTOR 2 |
| 293-1050 | | Movement Parts | DATE DIAL GUARD |
| 295-2900 | | Rechargeable Battery | RECHARGEABLE CELL |
| 310-3910 | | Movement Parts | SOLAR CELL |
| 701-9790 | | Movement Parts | TRAIN WHEEL BRIDGE |

| | | | |
|----------|--|----------------|-------------|
| 713-1280 | | Movement Parts | LOWER PLATE |
|----------|--|----------------|-------------|

| | | |
|----------|----------------|----------------------------------|
| 720-3670 | Movement Parts | CIRCUIT BLOCK SUPPORTER |
| 750-B760 | Movement Parts | METAL PLATE |
| 902-2210 | Movement Parts | BUZZER CONTACT SPRING |
| 902-2410 | Movement Parts | CONTACT SPRING FOR SOLAR CELL |
| 903-1380 | Movement Parts | SWITCH SPRING |
| 903-1450 | Movement Parts | STRAP FOR THIRD WHEEL |
| 923-1090 | Movement Parts | CIRCUIT BLOCK SCREW |
| 923-8600 | Movement Parts | CIRCUIT BLOCK SUPPORTER SCREW |
| 929-4800 | Movement Parts | SCREW FOR DATE DIAL GUARD |

