

Item code	Item category		Name
012-2440	Movement Parts		CENTER WHEEL
017-1640	Movement Parts		THIRD WHEEL & PINION
023-3570	Movement Parts		FOURTH WHEEL & PINION
027-1250	Movement Parts		CALENDAR PLATE GIB
067-1970	Movement Parts		SETTING LEVER
075-5160	Movement Parts		HOUR WHEEL
077-1380	Movement Parts		SETTING LEVER SPRING
078-3400	Movement Parts		DIAL WASHER
084-8300	Movement Parts		FIFTH WHEEL & PINION
087-2060	Movement Parts		INTERMEDIATE HOUR WHEEL 1
087-2070	Movement Parts		INTERMEDIATE HOUR WHEEL 2
100-6500	Movement Parts		INTERMEDIATE DATE WHEEL
103-1210	Movement Parts		DATE DIAL DRIVING WHEEL
186-7800	Movement Parts		SHIELD PLATE
190-1870	Movement Parts		STATOR 1
190-1890	Movement Parts		STATOR 2
212-2850	Movement Parts		SETTING STEM SPACER
213-4800	Movement Parts		SWITCHING WHEEL
227-6300	Movement Parts		SWITCH SPRING 1
227-6400	Movement Parts		SWITCH SPRING 2